



## WARNING

THIS FIXTURE IS DESIGNED TO USE TYPE B SINGLE-ENDED  
BALLAST-BYPASS BULBS ONLY.  
DO **NOT** USE FLORESCENT TUBES OR A DIMMER

## OVERHEAD LIGHT & OVERHEAD ARMS

Item Numbers 8500, 8504, 8505, 8510, 8538

Overhead Arms	2
End Caps	2
Basic Bolts	4 (Arms only) 8 (With light)
Basic Nuts	4 (Arms only) 8 (With light)

1. Insert two (2) Basic Bolts into mounting plate on Overhead Arm. Secure with Basic Nut. Turn only one revolution. Repeat for other Overhead Arm.
2. Insert Basic Nuts attached to Overhead Arm mounting plate into frame channel of workstation and turn Basic Bolt 90 degrees clockwise to grip. Top of mounting plate should be flush with top of frame cross member.
3. Insert a Basic Bolt from bottom into light mounting plate. Secure with Basic Nut. Turn only one revolution.
4. Position light unit with cord facing the frame. Insert Basic Nuts attached to light unit into Overhead Arm channel and turn Basic Bolt 90 degrees clockwise to grip.
5. Slide the light unit to the desired position. Tighten the bolts. Slide End Caps onto front ends of Overhead Arms.